

## electricc Pallet Truck Parts List 250218

For more spare parts, please contact us. Thank you very much!

1	1500500004	Handle assembly
2	2000512002	Lubricated bush(自润滑轴承)
3	2000513001	Pin shaft(销轴)
4	2000536001	Spring pin(弹性销)
5	2000534003	Rubber washer(缓冲垫)
6	2000931004	Screw(螺钉)
7	2000534002	Rubber sleeve(轴套)
8	2000508001	Outer covering plate
9	2000537002	Washer
10	2000541003	Screw(螺钉)
11	2000537001	Washer(垫圈)
12	2000508002	Inner covering plate(盖板)
13	4000517004	Handle socket(手柄支架)
14	1500500006	Electron handgrip(电子转向)
15	5501221001	Gear(主动齿轮)
16	2000541002	Screw(螺钉)
17	2000513003	Pin shaft(销轴)
18	2000541004	Screw(螺钉)
19	4300534001	Rubber sack(橡胶密封圈)
20	2000525004	Screw(螺钉)
21	5300517002	Handle (手柄)
22	6000131007	Screw (螺钉)
23	1001437003	Washer (垫圈)
24	1200518001	Supporting plate (支撑板)
25	2000527002	Snap ring (挡圈)
26	2000520003	Joint (下接头)
27	2000525006	Shaft (轴)
28	1000527001	Snap ring (挡圈)
29	2000527002	Snap ring (挡圈)
30	2000520003	Joint (下接头)
31	2000525006	Shaft (轴)
32	1000527001	Snap ring (挡圈)
33	4000517001	Covering plate (盖板)
34	2000542001	Screw (螺钉)
35	5300500002	Switch box assembly (控制盒总成)
36	4000517001	Covering plate (盖板)
37	2000542001	Screw (螺钉)
38	4300500005	Switch box assembly (控制盒总成)
39	6000131006	Screw (螺钉)
40	2000519004	Spring (弹簧)
41	4300500007	Cover assembly (手柄盖总成)
42	4300500004	Stepped switch assembly (行走开关总成)
43	2000507002	Emergency reverser button (紧急换向按钮)
44	4300517001	Handle (手柄)
45	6000131007	Screw (螺钉)

46	4300531001	Screw (螺钉)
47	2000535005	Installing plate(调整块)
48	2000504001	Steel ball(钢球)
49	2000507004	Inching switch(微动开关)
50	2000537003	Washer(垫圈)
51	2000541001	Screw(螺钉)
52	5500521001	Gear(被动齿轮)
53	9300200001	Sensor assembly(传感器总成)
54	1500500005	Handle assembly(手柄总成)
55	1500500004	Handle assembly (手柄总成)
56	5300500002	Switch box assembly (控制盒总成)
57	2000442001	Screw (螺钉)
58	4000517003	Handle tube (铝手把)
59	6000502002	Pneumatic spring seat (气弹簧座)
60	2000525012	Joint (气弹簧球头)
61	6000419001	Pneumatic spring complete (气弹簧)
62	5300518003	Emergency reverser button cover (紧急换向按钮盖)
63	2000519004	Spring (弹簧)
64	5300500001	Cover assembly (手柄盖总成)
65	4300500004	Stepped switch assembly (行走开关总成)
66	2000507002	Emergency reverser button (紧急换向按钮)
67	9300517001	Seat (微动开关座)
68	1000515002	Shell (接插件母胶壳)
69	1000515001	Shell (接插件公胶壳)
70	1000515001	Shell (接插件公胶壳)
71	4300500004	Stepped switch assembly(行走开关总成)
72	2000538005	Screw (螺栓)
73	2000507003	Inching switch(微动开关)
74	2000535001	Isolate block (绝缘块)
75	2001141005	Screw (螺栓)
76	1500500005	Handle assembly (手柄总成)
77	4300500005	Switch box assembly (控制盒总成)
78	6000131006	Screw (螺钉)
79	4300531001	Screw (螺钉)
80	9300517001	Seat (微动开关座)
81	1000515002	Shell (接插件母胶壳)
82	4300518003	Fastening bracket (固定支架)
83	1000504001	Washer (垫圈)
84	2000539002	Nut (螺母)
85	2000442001	Screw (螺钉)
86	4000517003	Handle tube (铝手把)
87	6000502002	Pneumatic spring seat (气弹簧座)
88	2000525012	Joint (气弹簧球头)
89	1500519001	Pneumatic spring complete (气弹簧)
90	4300508001	Emergency reverser button cover (紧急换向按钮盖)
91	1001437003	Washer (垫圈)
92	1200518001	Supporting plate (支撑板)

93	4300501005	Cam (凸轮)
94	4300513001	Cam Shaft (凸轮安装轴)
95	1002343003	Rack (齿条)
96	2000519004	Spring (弹簧)
97	4300900002	Screw (螺钉)
98	2001437005	Spring washer (垫圈)
99	4300540001	Right control knob (右控制手柄)
100	4300512001	Shaft sleeve (轴套)
101	4300535001	Fastening bracket (固定支架)
102	2000541004	Screw (螺钉)
103	4300540002	Left control knob (左控制手柄)
104	4300518004	Baffle (挡板)
105	2000521001	Gear (齿轮)
106	4700418001	Fastening bracket (固定支架)
107	4700400001	Potentiometer (电位器)
108	1500300001	Motor (电动机)
109	1000131001	Screw (螺栓)
110	2001037001	Washer (垫圈)
111	9300400002	Encoder (转向电机编码器)
112	5501221004	Gear (齿轮)
113	7800337001	Washer (垫圈)
114	7800330002	Screw (螺栓)
115	1500318001	Flange (浮动键)
116	300320001	Axletree (变速箱大轴承)
117	2000100002	Gear box assembly (齿轮箱总成)
118	5500332003	Drive wheel assembly (驱动轮总成)
119	2000325002	Nut (螺母)
120	8700406001	Limitation switch (光电开关)
121	9300312002	Sleeve (衬套)
122	7800321001	Gear (齿轮)
123	2000130002	Screw (螺栓)
124	7800321001	Gear (齿轮)
125	2000125001	Nut (螺母)
126	2000121006	Gear (齿轮)
127	2000120003	Bearing (轴承)
128	2000141001	Screw (螺栓)
129	2000625001	Bolt (六角头螺栓)
130	2000603010	Washer (垫圈)
131	2000111002	Sider cover (箱体侧盖)
132	2000128002	O-ring (O 型圈)
133	2000130001	Bolt (六角头螺栓)
134	2000105001	Seal washer (密封圈)
135	2000121003	Spline Shaft (花键轴)
136	2000126001	Gear box body (齿轮箱箱体)
137	2000130002	Screw (螺栓)
138	7800321001	Gear (齿轮)
139	2000125001	Nut (螺母)

140	2000135001	Washer (垫圈)
141	2000121002	Gear (齿轮)
142	2000120002	Bearing (轴承)
143	2000137001	Washer (垫圈)
144	2000137002	Washer (垫圈)
145	4000201001	Gear (齿轮)
146	4000101001	Flat (平键)
147	2001037001	Circlip (弹性挡圈)
148	2000731003	Screw (螺栓)
149	2000120001	Bearing (轴承)
150	2000121006	Gear (齿轮)
151	2000120003	Bearing (轴承)
152	2000141001	Screw (螺栓)
153	2000625001	Bolt (六角头螺栓)
154	2000603010	Washer (垫圈)
155	2000111002	Sider cover (箱体侧盖)
156	2000128002	O-ring (O 型圈)
157	4600113001	Nut (螺母)
158	2000121002	Gear (齿轮)
159	2000120002	Bearing (轴承)
160	2000137001	Washer (垫圈)
161	2000137002	Washer (垫圈)
162	1000600006	Valve assembly(阀体)
163	1000628001	O-ring(O型圈)
164	1000600007	Oil pump(油泵)
165	2000631003	Screw(螺栓)
166	2000631001	Screw(螺栓)
167	1000626002	Oil tank(油箱)
168	1000609001	Washer(垫圈)
169	1000741001	Screw(螺栓)
170	1000614005	Joint(接头)
171	1000605005	Plug(陶瓷透气塞)
172	4000201001	Gear (齿轮)
173	4000101001	Flat (平键)
174	2001037001	Circlip (弹性挡圈)
175	2000731003	Screw (螺栓)
176	2000120001	Bearing (轴承)
177	2000105001	Seal washer (密封圈)
178	4600113002	Spline Shaft (花键轴)
179	2000126001	Gear box body (齿轮箱箱体)
180	7800300003	Gear box assembly (变速箱总成)
181	301000001	Brake assembly(电磁制动器)
182	2001021001	Spline (花键轴套)
183	2001427001	Snap ring (轴用挡圈)
184	2001012001	Sleeve (定位套)
185	4600628001	O-ring (O 型圈)
186	4001404001	Flat key (平键)

187	301400001	Motor (电机)
188	301431001	Screw (螺栓)
189	301435001	Position sleeve (过渡定位套)
190	2001405001	Dust ring (骨架油封)
191	2001228001	O-ring (O 型圈)
192	2001420001	Bearing (轴承)
193	2001427001	Snap ring (轴用挡圈)
194	2001227003	Snap ring (轴用挡圈)
195	2000121005	Gear (齿轮)
196	2001435002	Semicircle key (半圆键)
197	2001425002	Nut (螺母)
198	4601402001	Joint (磁钢头)
199	301427001	Washer (垫圈)
200	2001441001	Screw (螺钉)
201	1801411001	Cover (刹车盘上盖)
202	1801411002	Wire saddle (线套)
203	7801006001	Circuit board (编码器线路板)
204	8700615004	Joint (接头)
205	6000637001	O-ring (O 型圈)
206	2401400001	Hydraulic motor(液压站电机)
207	1500614001	Hard oil pipe (硬油管)
208	1500603001	Soft oil pipe (软油管)
209	1500615001	Joint (接头)
210	4700613001	Piston rid (活塞杆)
211	2800605002	Dust ring (防尘圈)
212	4700612001	Supporting tach (导向环)
213	2800605001	Seal washer (密封圈)
214	1001400001	Hydraulic motor(电机)
215	2000612004	Connecting bearing sleeve(连轴套)
216	1000605006	Cover(油管盖)
217	2401400001	Hydraulic motor (电机)
218	1000131001	Screw (螺钉)
219	1800601001	Joint sleeve (电动机齿轮连轴套)
220	1800603001	Valve (阀)
221	1800628001	O-ring (O 型圈)
222	4900635001	Tank clamp ring (油箱夹圈)
223	2000931001	Screw (螺栓)
224	4900603001	Oil tank (油箱)
225	2000628010	O-ring (O 型圈)
226	1800639001	Nut (螺母)
227	4900614001	Joint (接管)
228	1000605005	Plug (陶瓷透气塞)
229	1000605006	Cover (油管盖)
230	4900600001	Hydraulic power unit (液压动力单元)
231	1500724001	Frame(车架)
232	1500724002	Bracket(手把支座)
233	7300300001	Balance wheel assembly(万向轮总成)

234	1500400001	Electric panel assembly(配电板总成)
235	1500724003	Frame (车架)
236	1500724002	Bracket (手把支座)
237	7300300002	Balance wheel assembly (万向轮总成)
238	2000541003	Screw (螺钉)
239	1500702001	Rung (面罩横档)
240	1000407002	Limit switch (限位开关)
241	1501100001	Electric panel assembly (配电板总成)
242	1501100002	Electric panel assembly(配电板总成 (冷库专用) )
243	1501100003	Electric panel assembly(配电板总成 (带互锁) )
244	1501100004	Bedrk: panel assembly(配电板总成 (冷库专用) (带互锁) )
245	7300300001	Balance wheel assembly (万向轮总成)
246	7300300002	Balance wheel assembly(new)(新款万向轮总成)
247	7300330001	Screw M12 (M12螺钉)
248	7300332001	Screw(new) M14 (M14新款螺钉)
249	2000305001	Dust ring (防尘圈)
250	2300312001	Bush (挡套)
251	1000320002	Bearing (轴承)
252	2700332001	Balance wheel (万向轮)
253	2700332003	Balance wheel(new)(新款万向轮)
254	4000312002	Wheel sleeve (轴套)
255	1000339001	Nut
256	1800339002	Nut(new) M14 (M14新款螺母)
257	7301218001	Wheel bracket (支架)
258	7301218002	Wheel bracket(new) (新款支架)
259	7300305001	Pressurize circle (油封)
260	1001031003	Screw (螺栓)
261	7300218001	Wheel sleeve (轮架)
262	7300712002	Mat (垫圈)
263	4300327001	Mat (止动垫)
264	4300304001	Nut (螺母)
265	1500400001	Electric appliance assembly (配电板总成)
266	1500418001	Install plate (安装板)
267	4000400025	Circuit board (电路板)
268	4000412001	Washer (垫圈)
269	2001141005	Screw (螺栓)
270	1500400002	Controller (控制器)
271	2001427001	Washer (垫圈)
272	1000441005	Screw (螺栓)
273	7800400002	1230 Controller
274	4600400003	1232 Controller
275	1000441006	Screw (螺栓)
276	4300407002	WPZ Contact
277	4900407001	SW Contact
278	2000407010	Fuse (保险丝)
279	4300407001	WPZ Contact
280	1800306001	SW Contact (SW接触器)

281	2001141001	Screw (螺栓)
282	2001437006	Washer (垫圈)
283	4300406003	Install plate (安装板)
284	2001437003	Washer (垫圈)
285	9300506001	Fuse (保险丝)
286	1501100001	Electric panel assembly (配电板总成)
287	1501100002	Electric panel assembly(配电板总成 (冷库专用) )
288	1501100003	Electric panel assembly(配电板总成 (带互锁) )
289	1501100004	Electric panel assembly(配电板总成 (冷库专用) (带互锁) )
290	4000831001	Screw(螺栓)
291	2001427001	Washer(垫圈)
292	1501106001	Controller(控制器)
293	1501135001	Install plate(安装板)
294	1700439001	Nut(螺母)
295	301031001	Screw(螺栓)
296	1001437003	Washer(垫圈)
297	9300506001	Fuse(保险丝)
298	1801106001	Contact(接触器)
299	1000435004	Fuse seat(保险丝座)
300	5501242001	Screw(螺栓)
301	4601200001	Circuit board(电路板)
302	1000441005	Screw(螺钉)
303	1800306001	Contactor(接触器)
304	6000418004	Install plate(安装板)
305	4601102002	Radiator(散热架)
306	7800400002	1230 Controller(1230控制器)
307	1000441006	Screw(螺钉)
308	2000512002	Bearing (自润滑轴承)
309	4700611001	Set (活塞杆接头)
310	1500902001	Pin (销)
311	4701323001	Compound bearing (托臂)
312	4701313001	Shaft (轴)
313	4000813002	Shaft (轴)
314	4000213001	Shaft (轴)
315	4000813003	Shaft (轴)
316	4000218002	Wheel fork (轮架)
317	1000225002	Screw (锥端紧定螺钉)
318	2000305001	Dust ring (防尘圈)
319	2000312001	Bush (挡圈)
320	1501324014	Forked frame
321	1501324015	Forked frame
322	1501324016	Forked frame
323	1501324017	Forked frame
324	1501324018	Forked frame
325	1501324019	Forked frame
326	1000313001	Shaft (轴)
327	1000320002	Bearing (轴承)

328	1000332001	Single wheel (单轮)
329	1000332004	Loading wheel (前双轮)
330	1000312003	Tube (套管)
331	1000320002	Bearing (轴承)
332	2000305001	Seal (密封圈)
333	2000312001	Ring (挡套)
334	1000302001	Plate (轮架夹板)
335	1000339002	Nut (螺母)
336	1000325003	Screw (螺栓)
337	1501324002	Forked frame
338	1501324003	Forked frame
339	1501324004	Forked frame
340	1501324005	Forked frame
341	1501324006	Forked frame
342	1501324007	Forked frame
343	1501324008	Forked frame
344	1501324009	Forked frame
345	1501324010	Forked frame
346	1501324011	Forked frame
347	1501324012	Forked frame
348	1501324013	Forked frame
349	1501324020	Forked frame
350	1501324021	Forked frame
351	1501324022	Forked frame
352	1501324023	Forked frame
353	1501324024	Forked frame
354	1501324025	Forked frame
355	4000822003	Link
356	4000822004	Link
357	4000822005	Link
358	4000822006	Link
359	1501324026	Forked frame
360	1501324027	Forked frame
361	1501324028	Forked frame
362	1501324029	Forked frame
363	1501324030	Forked frame
364	1501322001	Enhance Link
365	1501322002	Enhance Link
366	1501322003	Enhance Link
367	1501322004	Enhance Link
368	4000822001	Link
369	4000822002	Link
370	4000822007	Link
371	4000822009	Link
372	4000822010	Link
373	4000822011	Link
374	2001100021	Charger (220V Europe criterion)(欧标充电器)



375	2001100023	Charger
376	2001100024	Charger
377	2001100026	Charger
378	2001100024	Charger (220V Eng criterion)(英标充电器)
379	2001100026	Charger (110V USA criterion) (美标充电器)
380	4000822012	Link
381	4000822013	Link
382	4000822014	Link
383	4000822015	Link
384	4000822016	Link
385	2000407001	Emergency stop button(big)
386	1000407017	Emergency stop button(small)
387	2001116002	Battery indicator
388	1801116001	Key (钥匙开关)
389	1500908001	Veil (面罩)
390	2001100027	Charger (110V Australia criterion)(澳标充电器)
391	2001100028	Charger (110V Eng criterion) (英标充电器)
392	2001100029	Charger (110V Europe criterion)(欧标充电器)
393	1501100005	Flying rings (充电线)
394	1001100003	Battery(210Ah)(电瓶)
395	2000830001	Screw (防松螺栓)
396	2000937002	Washer (平垫圈)
397	2000937003	Washer (弹簧垫圈)
398	1500908002	Veil (面罩)
399	4300934001	Gripe (手把座)
400	1500908003	Veil (面罩)
401	1500902002	Gemel (铰链)
402	2000541002	Screw (螺钉)
403	1000239002	Nut (螺母)
404	4601108001	Cover (电线座盖)
405	2001100021	Charger
406	2001100022	Charger
407	2000937002	Washer (平垫圈)
408	2000937003	Washer (弹簧垫圈)
409	2001100027	Charger
410	2001100028	Charger
411	2001100029	Charger
412	1501100005	Flying rings (充电线)
413	1501102001	Battery case shell (电瓶箱外壳)
414	2000830001	Screw (防松螺栓)
415	2001100022	Charger (220V USA criterion) (美标充电器)
416	2001100023	Charger (220V Australia criterion)(澳标充电器)
417	1000239002	Nut (螺母)
418	4601108001	Cover (电线座盖)
419	6001100009	Battery (电瓶)