

electric pallet truck Spare Parts List 250227

For more spare parts, please contact us. Thank you very much!

1	20101030253	Power Cable
2	20101030247	Controller Cable +
3	20101030249	Pump Power Line +
4	20101030248	Controller Cable-
5	20101030252	Motor Cable
6	20101030242	Handle Wire
7	20101030243	Frame Wire
8	20301020042	Frame Wire
9	20301020043	Handle Wire
10	20101030253	Battery Wire
11	20101030252	Motor Cable
12	20101030247	Fuse-Controller
13	20301020039	Frame Wire
14	20301020038	Handle Wire
15	20101030253	Battery Wire
16	20101030252	Mmotor Cable
17	20101030247	Fuse-Controller
18	19.0345	Fuse
19	02.CDQ.3481	Asia Charger 24V/10A
20	02.CDQ.3495	EU Charger 24V/10A
21	02.CDQ.3496	U.S Charger 24V/10A
22	02.CDQ.3497	U.K Charger 24V/10A
23	02.01.9481	Low Voltage Protection
24	02.01.9397	Emergency Stop Switch
25	02.XDC.3451	Battery 24/20Ah
26	02.XDC.3471	Battery 24/20Ah
27	02.XDC. 3472	Battery 24/30Ah
28	02.XDC.3473	Battery 24/30Ah
29	02.XDC. 3474	Battery 24/40Ah
30	02.XDC. 3475	Battery 24/40Ah
31	30.01.1688	Rubber Mat
32	33.054.0003	battery Holder
33	33.054.0004	battery Holder
34	40.18.006	Elastic Splint
35	03.0146	Screw l6x8
36	03.0011	Lock Washer o6
37	03.0049	Flat Washer o6
38	03.0147	Screw M6x16
39	19.03620	Horn
40	03.02151	Screw M3x8
41	02.KZQ.2167	Controller
42	02. KZQ.2377	Controller
43	02.K2Q.2376	Controller
44	03.01410	Screw M5x25
45	03.0007	Lock Washer o5

46	02.01.3057	Fuse Block
47	03. 0133	Screw M5x16
48	03.0926	Flat Washer o5
49	02.01. 9153	Plug
50	02.01. 9028	Unidirectional Valve
51	02.01. 9068	Pressure Valve
52	02.YYL.3980	Oil Return Pipe
53	03.1062	O-Ring
54	02.01.9339	Tank
55	02.YYL.3989	Gear Pump
56	03.0007	Lock Washer
57	03.03646	Screw
58	03.00491	Flat Washer
59	03.0008	Lock Washer
60	03.0123	Screw
61	02.01. 2207	Relay
62	03.1045	Clamp
63	02.DJ. 3363 1	Motor
64	02.01.9367	Coil
65	02.01.9334	Solenoid Valve
66	19.1385	Silencer
67	02.01.90291	Relief Valve
68	02.01. 9332	Coupling
69	02.01.9353	Adapter
70	03.05162	O-Ring
71	02.YG.3690	Lifting Cylinder Assembly
72	02.01.9451	Piston Rod
73	02.01.9186	Ring Wiper
74	03.1073	Packing
75	02.01.9452	Cylinder Body
76	02.YG.3690-KIT	Seal Kit For Cylinder
77	GB/T3452.1-1992	O-Ring
78	ME2T-685-0050	Mandrel
79	C-15	Ejector Spring
80	MA2T-685-0270	Steel Bal1
81		Plug
82	GB/T3452.1-1992	O-Ring
83	ME2T-685-35-0060	Oil Pump Welding
84	MA2T-685-35-0170	Positioning Rod
85	H-3290	Valve Body
86	H-3310	Spoo1
87	H-3320	Spool Spring
88	C-7	Plug Serew
89	02.YG.3716-KIT	Seal Kit For Cylinder
90	MA2T-685-0100	Inner Cylinder
91	ME2T-685-0030	Pump Core
92	MA2T-685-0120	Gland

93	MA2T-685-0050	Spring
94	MA2T-685-0060	Dust Ring
95	MA2T-685-0180	Gasket
96	C-8	Plug Serew
97	C-17	
98	C-9	
99	ME2T-685-0040	
100	GB/T73-1985	
101	GB/T41-2000	
102	C-11	
103	CDB-MA2T-685-0240	
104	02. YG. 3716	Lifting Cylinder Assembly
105	ME2T-685-35-0001	Plunger Lever
106	DHS35	Dust Ring
107	GB/T3452.1-1992	O-Ring
108	UHS35	Seal Ring
109	MA2T-685-0050	Gasket
110	MA2T-685-0060	Plug Screw
111	ME2T-685-35-0002	Outer Cylinder
112	GB/T3452.1-1992	O-Ring
113	GB/T3452.1-1992	O-Ring
114	MA2T-685-35-0003	Inner Cylinder
115	71501000018	Handle Head Assembly
116	02.SB.PJ.0039	Upper Cover
117	02.SB.PJ.0040	Spring
118	02.SB.PJ.0041	Lift Button
119	02.SB.PJ.0042	Horn Button
120	02.SB.PJ.0060	Screw
121	02.SB.PJ.0043	Belly Switch
122	02.SB.PJ.0044	Spring
123	02.SB. PJ. 0045	Bracket
124	02.SB.PJ. 0046	Clamp
125	02.SB.PJ.0047	Harness Clamp
126	02.SB.PJ.0061	Screw
127	02.SB.PJ.0048	Card
128	02.SB.PJ.0049	Micro Switch
129	02. SB. PJ. 0052	Travelling Knob (R)
130	02.SB.PJ.0053	Accelerator Assembly
131	03.0123	Screw M4x10
132	02.SB. PJ. 0055	Bracket
133	02.SB.PJ.0063	Screw M4x6
134	02.SB.PJ.0056	Lower Cover
135	03.03644	Screw M5x50
136	02.SB.PJ. 0062	Screw M3x14
137	02.SB. PJ. 0057	Travelling Knob (L)
138	02.SB.PJ.0058	Shaft Sleeve
139	02.SB.PJ.0059	Shaft Jacket

140	001.01.90002001	Handle
141	001.01.90002006	DeclineButton
142	001.01.90002005	RisingButton
143	001.01.90002011	Horn
144	001.01.90002022	Spring
145	001.01.90002010	Inner Cover
146	001.01.90002004	Belly Switch
147	001.01.90002003	Accelerator Knob
148	0902-Z01-002	Switch
149	0902-Z03-011	Accelerator
150	001.01.90002002	Cover
151	001.01.90403004	Button
152	001.01.90101001	Screw
153	001.01.90111005	Screw
154	001.01.90107001	Nut
155	001.01.90107002	Nut
156	001.01.90105002	Lock Washer
157	001.01.90104001	Flat Washer
158	001.01.90111004	Screw
159	0902-Z02-002	Lift Button
160	001.01.90103003	Screw
161	001.01.90701002	Outline Border
162	001.01.90111002	Screw
163	001.01.90003014	Protect Shell
164	55220000029	Operating Handle Assembly
165	71501000018	Handle Head Assembly
166	03.0149	Screw
167	03.0011	Lock Washer
168	03.0049	Flat Washer
169	200101010007	Control Handle
170	02.01.2315	Shock Pad
171	03.0258	Nut M8
172	03.01301	Screw
173	03.00091	Lock Washer
174	02.01.9274	Proximity Switch
175	03.0692	Bushing
176	40.14.009	Pressing Roller
177	40.14.008	Shaft
178	03.0702	Round Pin
179	02.SB.ZJ.0003	Operating Handle Assembly
180	02.SB.3194	Handle Head Assembly
181	03.0150	Screw
182	03.0011	Lock Washer
183	03.0049	Flat Washer
184	40.16.055	Handle
185	02.01.2315	Shock Pad
186	03.0258	Nut

187	03.0692	Bushing
188	40.14.009	Pressing Roller
189	40.14.008	Shaft
190	03.0702	Round Pin
191	71501000016	Handle Head Assembly
192	71511000104	Horn Button
193	71511000105	Rising Button
194	71511000106	Decline Button
195	70103000018	Spring
196	71511000101	Upper Cover
197	70103000006	Switch
198	30231030004	Screw
199	71511000107	Micro Switch Card
200	70103000009	Micro Switch
201	30231030002	Screw
202	71511000117	Lower Cover
203	71511000103	Belly Switch
204	71511000108	Mode Button
205	71511000109	Mode Button Card
206	70601000018	Meter
207	20101040001	Key Switch Assembly
208	20101040002	Key Switch Assembly
209	71511000110	Key Box
210	30231030004	Screw
211	30201050013	Screw
212	70132000102	Accelerator Assembly
213	71511000115	Accelerator Knob
214	71511000113	Shaft Jacket
215	71511000111	Shaft Sleeve
216	30431080001	Spring Washer
217	70132000001	Accelerator
218	30211030008	Screw
219	02.SB.ZJ.0002	Operating Handle Assembly
220	71501000016	Handle Head Assembly
221	03.0147	SCrew
222	03.0011	Lock Washer
223	30.20.0013	Control Handle
224	02.01.2315	Shock Pad
225	03.0258	Nut M8
226	02.01. 9274	Proximity Switch
227	03.00091	Lock Washer
228	03.01301	Screw
229	03.0692	Bushing
230	40.14.009	Pressing Roller
231	40.14.008	Shaft
232	03.0702	Round Pin
233	71501000014	Handle Head Assembly

234	71511000104	Horn Button
235	715110000105	Rising Button
236	70103000018	Spring 7x16
237	71511000100	Upper Cover
238	70103000006	Swi tch
239	30231030006	Screw
240	71511000107	Micro Switch Card
241	71503000009	Micro Switch
242	30231030002	Screw
243	71511000102	Lower Cover
244	71511000103	Belly Switch
245	71511000108	Mode Button
246	71511000109	Mode Button Card
247	70601000018	Meter
248	20101040001	Key Switch Assembly
249	20101040002	Key Switch Assembly
250	71511000110	Key Box
251	30231030004	Screw
252	30201050013	Screw
253	70132000102	Accelerator Assembly
254	71511000115	Accelerator Knob
255	71511000113	Shaft Jacket
256	71511000111	Shaft Sleeve
257	30431080001	Spring Washer
258	70132000001	Accelerator
259	30211030008	Screw
260	81.005.002	Balance Wheel Assembly
261	40.11.044	Flange
262	03.0063	Circlips For Shaft
263	03.90.0011	Bearing
264	03.0027	Circlips For Holes
265	03.0372	Bolt
266	40.11.049	Bracket
267	03.0245	Nut M12
268	03.04790	Spring
269	40.11.048	Wheel Frame
270	03.90.042	Bearing
271	40.11.045	Sleeve
272	02.01.3368	Balance Wheel
273	03.01731	Screw
274	40.11.082	Sleeve
275	02.01.3368	Balance Wheel
276	03.01731	Screw M12x55
277	40.11.082	Sleeve
278	03. 0975	Parallel Key
279	02.01.3596	Brake Assembly
280	02.01.0284	Terminal Box

281	19.0526	Brush
282	19.05261	Brush
283	02.QD.0295	Driving Assembly
284	02.01.3703	Oil Seal
285	03.0147	Screw
286	03.0011	Lock Washer
287	02. QDL. 0272	Driving Wheel
288	02.QDL. 3316	Driving Wheel (Rubber)
289	02.DJ.00852	Motor
290	03.0716	Parallel Key
291	02.01.00702	Gear
292	03.0062	Circlips For Shaft
293	03.0061	Circlips For Shaft
294	02.01.006810	
295	02.01.9294	Spacer
296	03.0709	Circlips For Holes
297	02.01.00687	Gear
298	02.01.3681	Oil Seal
299	02.01.9287	Gear Box
300	03.0012	Lock Washer
301	03.0157	Screw
302	03.90.074	Bearing
303	02.01.00701	Gear
304	03.0717	Parallel Key
305	02.01.00703	Gear
306	03.90.075	Bearing
307	02.01.210707	Gear Box Cap
308	03.0719	Oil Seal
309	03.01049	Screw
310	03.0506	Grease Fitting
311	03.04350	Round Pin
312	03.0014	Lock washer
313	03.0043	Flat Washer
314	40.16.004	Driving Cover
315	40.16.001	Driving Cover
316	33.048.0021	Balance Frame L
317	20201000925	Balance Frame L
318	33.048.0022	Balance Frame R
319	20201000926	Balance Frame R
320	81.005.023	Balance Wheel Assembly
321	03.0049	Flat Washer
322	03.0011	Lock washer
323	03.0147	Screw
324	03.90.0121	Bearing
325	33.048.0001	Balance Frame Left
326	30.46.0063	Balance Frame
327	40.16.002	Bridge

328	33.048.0002	Balance Frame Right
329	40.14.052	Shaft
330	03.0306	Round Pin
331	03.90.091	Bearing
332	02.QD.0287	Driving Assembly
333	03.0165	Screw
334	03.0014	Lock washer
335	03.0043	Flat Washer
336	40.16.004	Driving Cover
337	40.16.001	Driving Cover (With Balance Wheel)
338	33.048.0021	Balance Frame L
339	20201000925	Balance Frame L
340	33.048.0022	Balance Frame R
341	20201000926	Balance Frame R
342	81.005.023	Balance Wheel Assembly
343	03.0049	Flat Washer
344	03.0011	Lock washer
345	03.0147	Screw
346	02.SB.ZJ.0002	Operating Handle Assembly
347	02.SB.ZJ.0003	Operating Handle Assembly
348	55220000029	Operating Handle Assembly
349	40.16.042	Rotation Shaft
350	03.0303	Round Pin
351	03.07391	Steel Bal1
352	02.YG.3690	Lifting Cylinder Assembly
353	03.0156	Screw
354	03.0012	Lock Washer
355	40.16.044	Mounting Plate
356	03.0149	Screw
357	03.0011	Lock Washer
358	40.16.045	Mounting Plate R
359	02.01.9354	Check Ring
360	03.05131	0 Sharp Ring
361	02.DLDY.3475	Power Unit Assembly(Electric lowering)
362	03.0226	Screw M5x12
363	02.KSCX.0002	Motor Cover RD
364	02.FGJ. 3463	Motor Cover GN
365	03.0159	Screw M8x40
366	40.16.043	Driving Block
367	40.16.046	Piston Rod
368	40.16.047	Top Cover
369	03.1060	Spring
370	03.0043	Flat Washer
371	40.16.004	Driving Cover
372	40.16.001	Driving Cover
373	33.048.0021	Balance Frame L
374	20201000925	Balance Frame L

375	33.048.0022	Balance Frame R
376	20201000926	Balance Frame R
377	81.005.023	Balance Wheel Assembly
378	03.0049	Flat Washer
379	03.0011	Lock washer
380	03.0147	Screw